

Model	Other model names	Date	Revision	Revision date
Regulator Assembly		2018-07-10	EN.18.02	2019-04-23

## How to install a regulator in a Royale, Bobcat MkI, Verminator MkII or Gladiator MkII

1. Remove the stock from the action.
2. Remove the airtube/bottle and the valve bracket (1) and the plastic gasket (2) which is located 10mm inside of the valve bracket (1).
3. Remove the manometer, you will see a 2mm diameter hole just under the manometer (marked with a red dot in the picture), this will have to be drilled through using a 2mm drill. **Important is to remove the aluminum chips from the block.**
4. Change the plastic gasket under the manometer and mount the manometer back. Tighten it carefully until you can feel it touching the plastic gasket and then add a half to one whole turn to the manometer depending how you want the manometer to sit.
5. Now insert the regulator as shown below just push it into place, and tightly screw the valve bracket (1) back. Reattach the airtube/bottle and the stock!

